



HOT DESK USER GUIDE

FOR PANASONIC KX-T76XX & KX-DT3XX SERIES HANDSETS

HOT DESK

FROM ANY EXTENSION

DIAL *727 + YOUR PREVIOUS EXTENSION NUMBER + YOUR PERSONAL PIN NUMBER

When using hot desk your previous extension will become the extension you use hot desk from. Most features will follow such as key programming, DDI number, call barring, and class of service. On returning to your own desk repeat code. Requires personal pin programming (Refer to programming sheet).

In default the personal pin number is 1234.

Southern Business Communications Ltd

Head Office - Southern Business Communications Ltd, Unit 1, The Broadway, Andover, Hampshire, SP10 2JF
Telephone: 01264 336644 - Fax: 01264 332083 - email: info@sbclimited.co.uk