



## **STORING AND ACCESSING SYSTEM SPEED DIALS USER GUIDE**

### **FOR PANASONIC KX-T76XX & KX-DT3XX SERIES HANDSETS**

#### **MANAGERS PROGRAMMING**

##### **STORING SYSTEM SPEED DIALS**

1. PRESS PROGRAM
2. DIAL \*#1234
3. DIAL 001
4. PRESS ENTER
5. DIAL LOCATION NUMBER (000-999)
6. DIAL 9 + TELEPHONE NUMBER
7. PRESS ENTER
8. PRESS THE NEXT BUTTON AND REPEAT STEPS 6 & 7 FOR NEXT LOCATIONS
9. PRESS HOLD TO END
10. LIFT HANDSET THEN REPLACE

##### **TO ACCESS SYSTEM SPEED DIALS**

1. LIFT HANDSET
2. PRESS AUTODIAL STORE + LOCATION NUMBER

##### **STORING SYSTEM SPEED DIAL NAMES**

1. PRESS PROGRAM
2. DIAL \*#1234
3. DIAL 002
4. PRESS ENTER
5. DIAL LOCATION NUMBER (000-999)
6. PRESS ALPHA – NUMERIC KEYPAD FOR LETTERS  
E.g. for letter (C) press (A) button 3 times  
Use > button where 2 letter land on the same button
7. PRESS ENTER
8. PRESS THE NEXT BUTTON AND REPEAT STEPS 6 & 7 FOR NEXT LOCATIONS
9. PRESS HOLD TO END
10. LIFT HANDSET THEN REPLACE

Southern Business Communications Ltd